

Instructions, item no: 791242

Please read the following instruction carefully before using the product!

WARNING:

- Don't plug in socket-outlet an appliance where the load exceeds 16Amp, always ensure the plug of any appliance is fully inserted into the socket-outlet.
- Don't immerse the product in water or any other liquid.
- Do use this product vertically, do not allow the direction of the socket-outlet to move towards the sky or incline.
- Install the socket-outlet away from heating emitting appliance.
- Don't install the socket-outlet where excessive moisture is present.
- Don't plug extension cord into the socket-outlet
- Plug the socket-outlet into a three wire grounded outlet only.
- Socket-outlet is rewirable, only use cord H07RN-F3G1.5mm².
- Don't plug in series.
- Don't use covered.

CONCRETE OPERATION INSTRUCTION:

- First take off the rubber cap, and then choose the suitable position to insert it into earth vertically and firmly.
- Insert the plug of this product into the socket that can be connected.
- Insert the grass-cutter (or other electronic appliance) in the socket of the product, press the switch or appliance, it can work.

INSTRUCTION OF TIMER:

TO Set the Time

Rotate the dial clockwise until the current time is lined-up with the arrow on the dial face. The hours are marked around the edge of the dial in 24 Hour format. Each marker between the hour numbers represent 15 minutes.

TO Set the Timer

The timer is triggered by the black push down/pull out segments located around the dial. Each segment represents 15 minutes.

Example

One segment is pushed down at number 16. The timer will switch the chosen appliance on/off at 16:00(4:00pm) and switch off/on at 16:15(4:15pm).

The timer will permit up to 96 on/off programmer in on one 24 hour period.

To select a segment to the 'switch on' position push down the chosen segment by using a ballpoint pen, small screwdriver or other similar implement. To de-select a segment pull out.

To Operate

Setting the timer to the desired on/off programmer.

Set the switch located on the side of the timer to clock for timer operation. Ensure the current time is set correctly on the timer dial.

Note: Set the switch on the other position to bypass timer operation and use appliances as normal.

PARAMETER:

Rated Voltage: 250V AC 50Hz

Rated Current: 16Amp, 3600W

Operating temperature:-25 to 55°C

Degree of Protection: IP44

Accuracy: +/-6 minute per day

DO NOT OVERLOAD